INSTALLATION INSTRUC

Attention: When ordering parts, it is very important that **part number** and **description** of part coincide.

PROPER INSTALLATION SEQUENCE:

See Figure 1 for log placement illustration.
See Figure 2 for burner pin locations.*
Attention: Do not use Log Placement pages to order replacement logs. Refer to Page 5, Parts List and Parts View to order logs for your appropriate model number.

The following WARNING applies when log set is installed onto an unv pa8 Twgas burnr lassembly

FRONT VIEW

TOP VIEW

LX-(24,30)WR-1 LOG PLACEMENT

4. Place Left Rear Log (D) on to Left Pin (8) on Rear Log Shelf and resting on burner base.

FRONT VIEW

TOP VIEW

LX-(24,30)WR-1 LOG PLACEMENT

5. Place Top Log (E) so that the round recess ýts over the round boss on the Left Rear Log (D) and the rectangle boss ýts into the rectangle recess on the Left Front Log (B).

FRONT VIEW

TOP VIEW

LX-(24,30)WR-1 PLACEMENT OF GLOWING EMBERS

USE ONLY MANUFACTURER'S REPLACEMENT

PROPER INSTALLATION SEQUENCE:

LX-(24,30)WRS-1 LOG PLACEMENT

3. Place Right Rear Log (C) onto Right Pin (3) on Rear Log Shelf. When placed properly, Left Front Log (B) and Right Rear Log (C) will look like a single log.

FRONT VIEW

TOP VIEW

LX-(24,30)WRS-1 LOG PLACEMENT

5. Place Top Middle Log (E) so the long boss ýts into the long recess on the Left Rear Log (D) and the short boss ýts into the short recess on the Left Front Log (B).

FRONT VIEW

TOP VIEW

LX-(24,30)WRS-1 LOG PLACEMENT

6. Place Top Left Log (F) onto the rear round boss on the Top Middle Log (E) and the rectangle boss of the Left Rear Log

LX-(24,30)WRS-1 LOG PLACEMENT

7. Place Top Right Log (G) so that the boss goes into the recess on the Right Rear Log (C) and rests on the Right Front Log (A).

FRONT VIEW

TOP VIEW

LX-(24,30)WRS-1 PLACEMENT OF GLOWING EMBERS

LX-(24,30)WRS-1 PLACEMENT OF GLOWING EMBERS